

# W18-W User Guide

## I. Product Overviews



1. Date

2. Set/Confirm Button

3. Hourly chime Indicator

4. 12/24 Hour

5. Hour

6. week

7. Mode Button

8. Countdown Timer Indicator

9. Start/ Pause /Adjust Button

10. Second

11. Minute

12. Light Button

13. Alarm Indicator

## II. Time Setting

### 2.1 Seconds

On the default page, long press the "SET" button until the second starts blinking, then press the "ADJ" button once make Second zero.



### 2.2 Hour

Press the "Mode" button once, then the blinking will go to Hour, press "ADJ" button to adjust Hour



### 2.3 Minute

Press the "Mode" button again, then the blinking will go to Minute, press "ADJ" button to adjust Minute



## 2.4 Month

Press the "Mode" button again, then the blinking will go to Month, press "ADJ" button to adjust Month



## 2.5 Date

Press the "Mode" button again, then the blinking will go to date, press "ADJ" button to adjust date



## 2.6 Week

Press the "Mode" button again, then the blinking will go to week, press "ADJ" button to adjust week




## 2.7 12/24 Hours

Press the "Mode" button again, then the blinking will go to 12 or 24 hours format, press "ADJ" button to choose 12 hours format or 24 hours format



## 2.8 Confirm all the settings

Finally press "SET" button once to confirm all the time settings.



### III. Stop Watch

3.1 On the default page, press "Mode" button once, then the watch will go to SP mode(stop watch mode)



3.2 On stop watch mode, press "ADJ" button to start stop watch function



3.3 Press "ADJ" button again to pause stop watch function



3.4 Press "SET" button once to make stop watch zero.



## IV. Alarm Clock

### 4.1 Alarm Clock Time Setting

4.1.1 On the default page, press "Mode" button twice, then the watch will go to AL mode(alarm clock mode)



4.1.2 Long press the "SET" button until the Hour starts blinking, then press the "ADJ" button to adjust hour



4.1.3 Press the "Mode" button again, then the blinking will go to Minute, press "ADJ" button to adjust minute



4.1.4 Press the "Mode" button again, then the blinking will go to L1/L2, press "ADJ" button to choose L1 or L2.



*<Note>: (L1) is the alarm clock for the current time; (L2) is the alarm clock for the other time zone. Dual time setting please take reference to VIII.*

4.1.5 Press "SET" button once to confirm alarm clock time.



## 4.2 Alarm Clock Turn On/ Turn OFF

On the alarm clock mode, press the "ADJ" button alternately to turn on or turn off the alarm clock function. When the watch shows below, indicates the alarm clock has been turn on.





<Note>: Please press any button to end the alarm.

## V. Hourly Chime Function Turn ON/ Turn OFF

On the alarm clock mode, press the "ADJ" button alternately to turn on or turn off the hourly chime function. When the watch shows below, indicates the hourly chime function has been turn on.



## VI. Countdown Timer

**6.1** On the default page, press "Mode" button three times , then the watch will go to TR mode(countdown timer mode)



## 6.2 Countdown Timer Time-setting

6.2.1 Long press the "SET" button until the Hour starts blinking, then press the "ADJ" button to adjust hour



6.2.2 Press the "Mode" button again, then the blinking will go to Minute, press "ADJ" button to adjust minute



6.2.3 Press the "Mode" button again, then the blinking will go to Second, press "ADJ" button to adjust Second



6.2.4 Press "SET" button once to confirm countdown Timer Time-setting.



## 6.3 Countdown Timer Function Turn ON

6.3.1 On the TR mode, press the "ADJ" button once to turn on countdown timer function.



### 6.3.1 Countdown Pause

Press the "ADJ" button again to pause countdown.



## VII. Back Light

7.1 On any mode, press the "LIGHT" button once to turn on back light.



## VIII. Dual Time Setting

8.1 On the default page, press "Mode" button four times, then the watch will go to T2 mode. On this mode, you can set up another time zone.



8.2 Long press the "SET" button until the Hour starts blinking, then press the "ADJ" button to adjust hour



8.3 Press the "Mode" button once, then the blinking will go to Minute, press "ADJ" button to adjust minute



8.4 Press "SET" button once to confirm setting.



*<Note>: Only Hour and Minute can be adjusted in this time zone.*