

User Manual

Model Number: W70 / W71

I. Product Overview

- | | |
|-----------------|---------------------------|
| 1. Week Day | 7. Date |
| 2. RESET Button | 8. ST/STP Button |
| 3. Hour | 9. Hourly Chime Indicator |
| 4. PM Indicator | 10. Alarm Indicator |
| 5. MODE Button | 11. Light Button |
| 6. Minute | 12. Second |

II. Alarm

2.1 Set an alarm

2.1.1 In the local time display mode, hold down the MODE button till you see the hour digit is blinking, then press the RESET button to set the hour.

2.1.2 Press the ST/STP button once, you will see the minute digit starts blinking, then press the RESET button to set the minute.

2.1.3 Press the MODE button once to save the setting and exit the alarm setting mode.

2.2 Turn On/Off Alarm

In the local time display mode, press ST/STP and RESET button at the same time to turn on or turn off the alarm.

III. Turn On/Off Hourly Chime Function

3.1 In the local time display mode, press the ST/STP and RESET button at the same time to turn on or turn off the hourly chime function.

IV. Local Time Setup

4.1 In the local time display mode, hold down the MODE button till you see the hour digit is blinking, then press the MODE button again, you will see the seconds digit is blinking, then press the RESET button to clear the seconds digit or you could skip to the next step.

4.2 Press the ST/STP button once, you will see the minute digit starts blinking, then press the RESET button to set the minute.

4.3 Press the ST/STP button once again, you will see the hour digit starts blinking, then press the RESET button to set the hour.

4.4 Press the ST/STP button once again, you will see the month digit starts blinking, then press the RESET button to set the month.

4.5 Press the ST/STP button once again, you will see the date digit starts blinking, then press the RESET button to set the date.

4.6 Press the ST/STP button once again, you will see the week day digit starts blinking, then press the RESET button to set the week day.

4.7 Press the MODE button once to save all the settings, the watch will back to the local time display mode.

V. LAP Stopwatch Mode

5.1 In the local time display mode, press the MODE button once to enter into stopwatch mode.

5.2 Press the ST/STP button to start timing.

5.3 Press the RESET button once to show the first lap read, the watch is still working for the second lap time counting.

5.4 Press the RESET button once to show the 2nd lap read, the watch is still working for the third lap time counting.

5.5 Keep pressing RESET button to show more lap reads.

5.6 Press the ST/STP button again to stop timing.

5.7 Press the RESET button to clear.

5.8 Press the MODE button once to exit the stopwatch mode.

Notes:

1. The stopwatch timing range is 0'00"00 to 23:59'59".

2. If you don't stop the timing, the stopwatch will continue to timing and start timing from 0'0"00 even the timing is over 24 hours and you have exited the stopwatch mode.

VI. Back Light

Press the LIGHT button to turn on the electro luminescent backlight. The backlight will be turned off automatically in about 3 seconds.

VII. 12/24 Hours Display Format Switch

In the local time display mode, hold down the ST/STP button, then press the mode button to switch the hour display format.

VIII. Check the month and date

Hold down the ST/STP button to check the current month and date.

